





HL3

For warranty and distributor information in your country, visit: www.COASTportland.com

HL3 INSTRUCTIONS:

BATTERY INSTALLATION:

The HL3 uses three AAA alkaline batteries. The batteries are housed in the rear of the headlamp.

To access the battery compartment, pull the elastic headband slightly away from the battery pack. Remove the rubber battery case cover by grasping the tab at the top of the cover and pulling it away from the battery pack.

Insert the batteries in the direction indicated inside the battery pack. Replace rubber battery case cover, making sure that the cover is placed evenly over the rim of the case.

LIGHT OPERATION:

To turn on the light, depress the silver switch on the bottom of the head of the light.

To turn off the light, depress the silver switch on the bottom of the head of the light a second time.

BEAM POSITION:

The hinged beam adjustment allows you to tilt the beam of light down into position to illuminate objects directly in front of you or in your hands. To adjust, grasp the head of the light at the top and bottom between your thumb and index finger and move the head of the light downwards.

HEAD STRAP ADJUSTMENT:

To adjust the HL3 to fit your head, first, slide the buckle on the left side of the head strap to adjust the strap to fit the circumference of your head. It may be necessary to slide the head of the light and battery pack on the head strap to center the light once the headband is adjusted to the proper size.

Then, adjust the top strap by sliding the buckle forward or back.

HARD HAT SAFETY HELMET CLIP USE:

The HL3 includes helmet clips for use with hard hat style safety helmets. To use the helmet clips, loosen the side of the headband to fit the helmet and attach the clips to the side strap of the headlamp, evenly spaced with two on each side.

Note: One of the clips has a wider loop to fit over the area on the side headband where the Z cord is located. Put the headlamp on the safety helmet and attach the clips to the rim of the heimet. Some adjustment of the clip positions and head straps will be necessary for proper fit on safety helmets.

Note: Clips are designed for use ONLY with HARD HAT style safety helmets. They are not acceptable for use on most sporting safety helmets.

MAINTENANCE:

Wipe the external body with a cloth moistened with water or isopropyl alcohol. Allow to dry before use. Do not submerge.